


viscount

Optional Pedalboards 25 – 18 notes

IT

ISTRUZIONI PER L'UTILIZZO CON GLI STRUMENTI DELLA SERIE LEGEND

- Non è necessario utilizzare alcun alimentatore esterno.
- Collegare il connettore [MIDI OUT] della pedaliera al connettore [PEDALS KEYB ONLY] dello strumento utilizzando il cavo MIDI fornito con la pedaliera stessa od un cavo con connettore DIN a 5 fili.
- Collegare il cavo EXPRESSION al connettore [EXP] per controllare il volume dello strumento tramite il pedale d'espressione della pedaliera.
- Collegare il cavo ROTARY al connettore [ROTARY] per controllare la velocità del Rotary con il dispositivo a leva del pedale d'espressione.
- Collegare il cavo ROTARY al connettore [HOLD] per controllare l'effetto Hold con il dispositivo a leva del pedale d'espressione.




ISTRUZIONI PER L'UTILIZZO CON QUALSIASI ALTRO STRUMENTO


- L'alimentatore esterno è opzionale. Le specifiche dell'alimentatore da utilizzare sono: 12V DC, 1A, polarità $\ominus \text{---} \oplus$.
- Collegare l'alimentatore al connettore [12V DC] della pedaliera.
- Collegare il connettore [MIDI OUT] della pedaliera al connettore MIDI di ingresso dello strumento.
- Collegare il cavo EXPRESSION ad un ingresso per il controllo continuo del volume dello strumento.
- Collegare il cavo ROTARY un ingresso che necessiti di un controllo switch N.A.

INSTRUCTIONS FOR USE WITH THE INSTRUMENTS OF THE LEGEND SERIES

- No external power supply is required.
- Connect the [MIDI OUT] connector of the pedalboard to the [PEDALS KEYB ONLY] connector of the instrument using the MIDI cable supplied with the pedalboard or a cable with a 5-wires DIN connector.
- Connect the EXPRESSION cable to the [EXP] connector to control the instrument volume using the pedalboard expression pedal.
- Connect the ROTARY cable to the [ROTARY] connector to control Rotary speed with the lever on the expression pedal.
- Connect the ROTARY cable to the [HOLD] connector to control the Hold effect with the lever on the expression pedal.



INSTRUCTIONS FOR USE WITH ANY OTHER INSTRUMENT

- The external power supply is optional. Specifications of the power adapter to be used: 12V DC, 1A, polarity .
- Connect the power adapter to the pedalboard connector [12V DC].
- Connect the [MIDI OUT] connector of the pedalboard to the MIDI input connector of the instrument.
- Connect the EXPRESSION cable to a suitable input for continuous instrument volume control.
- Connect the ROTARY cable to an input that requires a switch control, N.O. type.